
CableEye[®]

PC-Based Cable Test System

Patent 5,280,251

User's Guide

Windows Version

**Copyright © 1999 - 2004
by CAMI Research Inc.**

All rights reserved. This manual, the software screen designs, the database text, and the help text are copyrighted materials and as such are protected by the copyright law. They may not be reproduced by any means, including photocopy, lithographic, mechanical, recording, electronic retrieval, or microfilm.

The name "CableEye" and the CableEye logo are registered trademarks of CAMI Research Inc.



442 Marrett Road
Lexington, Massachusetts 02421

Tel: (781) 860-9137
Fax: (781) 860-9139
e-mail: tech@camiresearch.com
Web: www.camiresearch.com

Updates to this Manual

CAMI Research works continuously to improve and advance the CableEye® software. As a result, this hard-copy User's Guide can only represent a snapshot of the software at one moment in time and may not fully describe a newer version of the software that you may be using. Should you find functions in the software that are not described within, please refer to the Customer Services section of our web site:

www.camiresearch.com

Click on the "Customer Services" link, enter your User Name and Password, and proceed to the "User's Guide" section. There you will find the most recent version of the User's Guide available in .pdf format for downloading and printing.

We provide all customers with a User Name and Password when they purchase their equipment. The access codes remain valid for one year following purchase, and will remain active after one year when the Extended Warranty is purchased. If you have lost or misplaced your access codes, contact us and we will be pleased to look up this information. Be sure to have your serial number available.

Tel: (800) 776-0414

Fax: (781) 860-9139

e-mail: tech@camiresearch.com

The first three sections of this manual describe Software version 4.0, released February, 2002. Section 9 describes PinMap v3, released September, 2002. Section 15 describes Software version 4.2, released April 2004. This document was written and illustrated by Christopher E. Strangio.

Table of Contents

1	INITIAL SETUP	
1.1	CableEye Parts List	1-1
1.2	Equipment You Need	1-2
1.3	Hardware Setup	1-3
1.4	Software Setup (Windows 95/98/NT/2000/XP)	1-7
1.5	Software Setup (DOS)	1-9
1.6	PinMap™ and Exporter™ Software.....	1-10
1.7	Starting the CableEye Software.....	1-10
1.8	Possible Startup Problems	1-10
1.9	Screen Layout and Controls (Windows).....	1-11
1.10	Ready to Test!.....	1-12
2	THE CABLEEYE TEST FIXTURE	
2.1	General Description.....	2-1
2.2	Controls and Connectors	2-7
2.3	Static Discharge Precautions	2-11
2.4	Use of the External Ground Wire	2-13
2.5	Serial Interface.....	2-13
2.6	Test Point Connectors.....	2-14
2.7	Inserting Connector Boards	2-15
2.8	Test Point Driver Circuit	2-15
2.9	Cable Resistance Thresholds	2-16
2.10	Measuring Long Cables.....	2-17
3	THINGS YOU SHOULD KNOW ABOUT CABLEEYE	
3.1	Processing Cable Data	3-1
3.2	Screen Layout and General Operation.....	3-2
3.2.1	Operator Controls	3-2
3.2.2	Summary Boxes	3-2
3.2.3	Secondary Controls.....	3-5
3.2.4	Display Windows	3-5
3.2.5	Special Functions.....	3-7
3.2.6	Descriptive Notes and Labels.....	3-8
3.2.7	Use of Hot Keys	3-8
3.2.8	Warning and Advisory Messages	3-9
3.2.9	Warning and Advisory Tones	3-9
3.2.10	Operation Status Indicators	3-10
3.3	Using CableEye's Functions.....	3-11
3.4	Printing Reports and Labels.....	3-13
3.5	Software Operation without the Test Fixture Connected	3-14

3.6	On-Line HELP System.....	3-14
3.7	File Name Conventions.....	3-14
3.8	Subdirectory Options	3-17
3.9	The CableEye Database.....	3-18
3.10	Importing and Exporting Cable Data	3-19
3.11	Operating in a DOS Environment	3-20
3.12	Using Connector Boards	3-20
3.13	ID Jumpers on Connector Boards	3-22
3.14	Sharing Test Points on Connector Boards	3-22
3.15	Suggested Cable Attachment Rules	3-25
3.16	Testing Cables with More than Two Connectors.....	3-25
3.17	Connector Graphics	3-26
3.18	Write-Protecting Your Cable Data, Macros, and Preferences.....	3-27
3.19	Calibration and Self-Test	3-28
3.20	Connector Wear-Out.....	3-30
3.21	Hot-Keys.....	3-30
3.22	CB Board Compatibility Chart	3-33
4	BASIC OPERATIONS	
4.1	Measuring a Cable	4-1
4.2	Learning a Good Cable.....	4-5
4.3	Comparing Two Cables	4-9
4.4	Checking for Intermittent Connections	4-12
4.5	Saving Cable Data in the Database.....	4-16
4.6	Loading Cable Data from the Database.....	4-20
4.7	Searching the Database for a Match.....	4-23
4.8	Deleting Cable Data from the Database	4-26
4.9	Editing Notes and Labels	4-28
4.10	Displaying Wiring Diagrams	4-31
4.11	Displaying and Editing Netlists.....	4-37
4.12	Editing Pin Labels	4-41
4.13	Clearing all Data Buffers	4-44
5	PRINTING REPORTS AND LABELS	
5.1	Printing Cable Documentation	5-1
5.2	Printing Labels.....	5-6
6	AUTOMATIC TESTING	
6.1	Using Macros to Automate Testing.....	6-1
6.2	The Macro Window	6-4
6.3	Executing Macros	6-5
6.4	Creating and Editing Macros	6-6
6.5	Macro Editing Summary	6-12

6.6	Macro Instructions Explained.....	6-13
6.7	Other Information about Macros.....	6-22
6.8	Macro Examples.....	6-24
7	DATA LOGGING	
7.1	Documenting Batch Tests	7-1
7.2	Macro Instructions for Data Logging	7-4
7.3	Notes and Comments about Data Logging	7-6
7.4	More Data Logging Examples.....	7-7
8	DESIGNING AND EDITING CABLES	
8.1	Creating New Cable Data.....	8-1
8.2	Applications for Create Netlist	8-3
8.3	Editing Existing Cable Files	8-4
9	ADAPTING TO CUSTOM FIXTURES AND WIRING HARNESSSES	
9.1	Connector Interfaces and Pin Maps	9-1
9.2	How CableEye Uses Pin Maps	9-2
9.3	Multi-Headed Cables and Wiring Harnesses	9-3
9.4	Overview of Map Creation.....	9-4
9.5	PinMap Terminology and Organization.....	9-7
9.6	Using the PinMap™ Software.....	9-9
	9.6.1 File Tree Display	9-9
	9.6.2 File and Map Controls.....	9-11
	9.6.3 Map Editing Controls.....	9-13
	9.6.4 Entering Test Points Manually (without the probe)	9-18
	9.6.5 Entering Test Points Automatically with the Probe.....	9-22
9.7	Map Entry Errors and Their Consequences	9-26
9.8	Testing Your Map	9-27
9.9	Examples	9-27
	Example 1: Interfacing Pigtail Cables	9-28
	Example 2: Using CB Boards that Do Not Use ID Jumpers	9-33
	Example 3: Testing Multi-Ended Cables	9-38
	Example 4: Testing Wiring Harnesses.....	9-46
	Example 5: Reordering Pin Numbers	9-53
	Example 6: Using CB Boards with Different Expander Cables.....	9-56
10	DATABASE UTILITIES	
10.1	Overview of the Exporter™ Software.....	10-1
10.2	System Requirements and Installation.....	10-3
10.3	Using Exporter	10-4
10.4	Record Format for Export and Import	10-8

11	GUIDED ASSEMBLY SOFTWARE	11-1
12	SETTING PREFERENCES	
12.1	General Information about PREFERENCES	12-1
12.2	SERIAL PORT	12-2
12.3	CONNECTORS	12-4
12.4	WIRING DISPLAY	12-7
12.5	PRINT OPTIONS.....	12-8
12.6	CONTROL	12-9
12.7	LABELS.....	12-10
13	MEASURING RESISTANCE WITH MODEL M3	
13.1	Model M3 Overview	13-1
13.2	Hardware Differences between CableEye Models M3 and M2	13-2
13.3	Resistance Measurement and Thresholds.....	13-4
14	ERROR AND ADVISORY MESSAGES.....	14-1
15	NEW SOFTWARE RELEASE NOTES	
15.1	User Names, Passwords, Privileges	15-2
15.2	Bar Code Scanning	15-4
15.3	Database Archive.....	15-5
15.4	New Reporting Features and Macros.....	15-7
15.5	Macro Examples	
16	TROUBLESHOOTING CABLES	
16.1	Testing RS232 Cables.....	16-1
16.2	Testing Single-Ended Cables	16-4
16.3	Testing Bare Wire Terminations.....	16-6
17	SELF-TEST AND CALIBRATION	
17.1	Testing the Fixture Electronics.....	17-1
17.2	Calibration Not Required	17-3
17.3	Year 2000 Compliance.....	17-4
18	WARRANTY	18-1

INDEX